

# 3M™ AEROSOL SPRAY ADHESIVE APPLICATION CHART

CONVENIENCE, SPEED AND A FISTFUL OF REAL WORK POWER



## 73

### PHOTOMOUNT

#### FEATURES

- Fast Setting
- Non wrinkling
- Precise spray pattern
- No bleed through

## 74

### FOAM FAST

#### FEATURES

- Fast tack
- Foam tearing strength
- Non-misting, precise spray control
- Variable width spray pattern

## 75

### REPOSITIONAL

#### FEATURES

- Provides "tape-like" bonds
- Adheres in seconds
- Permits material to be repositioned
- Resists bleeding, staining or wrinkling

## 76

### HIGH TACK

#### FEATURES

- Strong, one-surface bonds
- High temperature resistance
- Non-misting, precise spray control
- Variable width spray pattern

|   |   |   |   |   |
|---|---|---|---|---|
| APPAREL & FABRIC  |   | <ul style="list-style-type: none"> <li>• Fabric to soft foams</li> </ul>  | <ul style="list-style-type: none"> <li>• Pattern lay up</li> <li>• Trim fixturing</li> <li>• T- shirt silk screening (temp hold)</li> <li>• Quilt lay up</li> </ul>   | <ul style="list-style-type: none"> <li>• Jute backed carpet repair</li> </ul>   |
| CONSTRUCTION  |   |   |   | <ul style="list-style-type: none"> <li>• Pipe insulation lap adhesive</li> <li>• Seal polyethylene under concrete</li> </ul>  |
| ART & CRAFT   | <ul style="list-style-type: none"> <li>• Scrap Booking</li> <li>• General photo adhesion</li> </ul> |   |   |   |
| DISPLAYS<br>JEWELLERY<br>SIGNS<br>SHELVING                          |   | <ul style="list-style-type: none"> <li>• Foam backup supports to panels</li> </ul>  | <ul style="list-style-type: none"> <li>• Dry mounting lay up</li> <li>• Labels</li> <li>• Posters</li> <li>• Prints</li> <li>• Delicate fabrics</li> <li>• Papers</li> </ul>  | <ul style="list-style-type: none"> <li>• Panels</li> <li>• Attach fabrics and carpet</li> </ul>   |
| PACKAGING   |   |   |   | <ul style="list-style-type: none"> <li>• Inner packing attachment</li> <li>• Seal poly bags</li> <li>• Labels to rubber tires</li> </ul>  |
| FURNITURE<br>UPHOLSTERY<br>CABINETS<br>WOODWORKING                  |   | <ul style="list-style-type: none"> <li>• Foams</li> <li>• Flexible foams</li> <li>• Fabrics</li> <li>• Reupholstery</li> <li>• Padding</li> <li>• Fabric repair of partitions</li> <li>• Mattress assembly</li> </ul> | <ul style="list-style-type: none"> <li>• Holding cutting templates in place</li> </ul>  | <ul style="list-style-type: none"> <li>• Foams</li> <li>• Fabrics</li> <li>• Repair office panel coverings</li> <li>• Decorative veneer to cabinets</li> </ul>  |
| PRINTING  |   |   | <ul style="list-style-type: none"> <li>• Layouts/ pasteups</li> <li>• Silkscreen pattern adhesive</li> </ul>  | <ul style="list-style-type: none"> <li>• Offset master attachment</li> <li>• Roll changes</li> <li>• Business forms</li> <li>• Layouts/pasteups</li> <li>• Silkscreen pattern adhesive</li> </ul>   |
| TRANSPORTATION  |   | <ul style="list-style-type: none"> <li>• Upholstery</li> <li>• Foams</li> <li>• Acoustics</li> <li>• Urethane foam seat covering</li> </ul>   | <ul style="list-style-type: none"> <li>• Pattern lay up</li> </ul>  | <ul style="list-style-type: none"> <li>• Van carpet</li> <li>• Truck cab foam</li> <li>• Door gaskets</li> <li>• Acoustical foam</li> <li>• Position gasket</li> </ul>  |
| GENERAL<br>PRODUCT<br>ASSEMBLY<br>RUBBER<br>PLASTIC<br>METALWORKING |   | <ul style="list-style-type: none"> <li>• Flexible foam to gun cases</li> <li>• Flexible foam to sample cases</li> <li>• Acoustical foam to equipment</li> <li>• Foam to motorcycle</li> </ul>                         | <ul style="list-style-type: none"> <li>• Mylar stencil mount</li> <li>• Temporary labels to equipment</li> <li>• Kit marking</li> <li>• Plant layout board</li> <li>• Bulletin board notices</li> <li>• Paper mills – roll starting</li> <li>• Stencil masking for sign painting</li> <li>• Temporary labels</li> </ul> | <ul style="list-style-type: none"> <li>• Nameplates</li> <li>• Cabinet coverings</li> <li>• Foam to fiberglass base</li> <li>• Motorized sweeper engine foam</li> <li>• Fabric to pottery base</li> <li>• Carpet to concrete and wood floors</li> </ul> |

73

74

75

76

# 3M™ AEROSOL SPRAY ADHESIVE APPLICATION CHART

CONVENIENCE, SPEED AND A FISTFUL OF REAL WORK POWER



## 77

### SUPER MULTIPURPOSE

#### FEATURES

- High coverage
- Versatile – securely bonds most lightweight materials
- Low soak-in for long lasting bonds
- Fast, aggressive tack
- Long bonding range

## 80

### NEOPRENE CONTACT

#### FEATURES

- Plasticizer resistance
- High temperature resistance
- Fast drying; fast bonding
- Non-misting, precise spray control
- Primes concrete

## 90

### HIGH STRENGTH

#### FEATURES

- High contact bond strength
- One-minute dry time
- High temperature resistance
- Non-misting, precise spray control
- Variable width spray pattern

|   |   |  |   |
|---|---|--|---|
| APPAREL & FABRIC  | <ul style="list-style-type: none"> <li>• Pattern lay up</li> <li>• Handbag linings</li> <li>• Holds appliques until sewn</li> <li>• Quilt lay up</li> <li>• Silkscreen printing</li> </ul>  | <ul style="list-style-type: none"> <li>• Leather bonding of belts</li> </ul>   | <ul style="list-style-type: none"> <li>• Leather bonding of belts</li> </ul>  |
| CONSTRUCTION  | <ul style="list-style-type: none"> <li>• Pipe insulation lap adhesive</li> <li>• Weather-stripping</li> </ul>   | <ul style="list-style-type: none"> <li>• Rubber pipe insulation</li> </ul>   | <ul style="list-style-type: none"> <li>• Pipe insulation lap adhesive</li> <li>• Seal polyethylene under concrete</li> </ul>  |
| ART & CRAFT   |   |  |   |
| DISPLAYS<br>JEWELLERY<br>SIGNS<br>SHELVING                    | <ul style="list-style-type: none"> <li>• Panels</li> <li>• Mock-up construction</li> <li>• Plastic letters</li> <li>• Decorative fabric</li> <li>• Paper coverings</li> <li>• Easel-backed cards</li> </ul>   | <ul style="list-style-type: none"> <li>• Panels</li> <li>• Attach fabrics and carpet</li> <li>• Decorative metal strips to plywood</li> </ul>  | <ul style="list-style-type: none"> <li>• Panels</li> <li>• Attach fabrics and carpet</li> <li>• Fabric to masonite</li> </ul>   |
| PACKAGING   | <ul style="list-style-type: none"> <li>• Palletizing</li> <li>• Drum labels</li> <li>• Foam inner packing</li> <li>• Shrink wrap attachment</li> <li>• Paper splicing</li> <li>• Inventory tags</li> <li>• Starting shrink film to pallets</li> </ul>   |  |   |
| FURNITURE<br>UPHOLSTERY<br>CABINETS<br>WOODWORKING            | <ul style="list-style-type: none"> <li>• Fabrics to foam</li> <li>• Lamp bottom fabric</li> <li>• Shade laminating</li> <li>• Pattern lay up</li> <li>• Prevent fabric edges from fraying</li> <li>• Picture framing</li> <li>• Mattress assembly</li> </ul>  | <ul style="list-style-type: none"> <li>• Foams/Fabrics</li> <li>• Repair office panel coverings</li> <li>• Decorative veneer to cabinets</li> <li>• High pressure laminate to particle board/plywood</li> <li>• Support vinyl</li> </ul>                             | <ul style="list-style-type: none"> <li>• Foams</li> <li>• Fabrics</li> <li>• Repair office panel coverings</li> <li>• Decorative veneer to cabinets</li> <li>• High pressure laminate to particle board/plywood</li> </ul>      |
| PRINTING  | <ul style="list-style-type: none"> <li>• Roll changes</li> <li>• Business forms</li> <li>• Layouts/pasteups</li> <li>• Silkscreen pattern adhesive</li> </ul>   | <ul style="list-style-type: none"> <li>• Plates to cylinders</li> <li>• Foam pads to die sets</li> <li>• Offset master attachment</li> </ul>   |   |
| TRANSPORTATION  | <ul style="list-style-type: none"> <li>• Aircraft interiors</li> <li>• Boat interiors</li> <li>• Scrim tacking prior to fibre glassing</li> </ul>   | <ul style="list-style-type: none"> <li>• Van conversions interiors</li> <li>• Insulation engine lids</li> <li>• Carpeting to plywood</li> <li>• Aircraft interiors</li> <li>• Vinyl bonded door panels</li> <li>• Door gaskets</li> <li>• Rubber flooring</li> </ul> | <ul style="list-style-type: none"> <li>• High pressure laminating</li> <li>• Interior trim</li> <li>• Rubber flooring</li> </ul>  |
| GENERAL PRODUCT ASSEMBLY<br>RUBBER<br>PLASTIC<br>METALWORKING | <ul style="list-style-type: none"> <li>• Box cushioning</li> <li>• Helmet cushioning</li> <li>• Fixturing</li> <li>• Sail making – fabric lay up</li> <li>• Architectural models</li> <li>• Grinding disc attachment</li> <li>• Hold down lane tapes</li> <li>• Paper mills – roll starting</li> <li>• Labeling and wrap repair</li> <li>• Fabric to bulletin boards</li> </ul> | <ul style="list-style-type: none"> <li>• Rubber pads</li> <li>• Rubber to metal</li> <li>• Rubber to rubber</li> <li>• Rigid PVC to PVC</li> <li>• Styrene to aluminium thresholds</li> <li>• Nameplates</li> </ul>  | <ul style="list-style-type: none"> <li>• Polyurethane foam to plywood instrument cases</li> <li>• Polyethylene to polypropylene in chemical bags</li> <li>• Fabric to pottery base</li> <li>• Name plates to plaques</li> </ul> |

77

80

90